



CS545-XD™, Convertible+  
Deluxe Charging Kit



CS540-XD™, Convertible



CS520-XD



CS510-XD

## IN THE BOX

### CS545-XD

Headset and battery base  
Headband  
Headset fit kit  
AC power supply

Telephone interface cable  
Other size eartips and earloops  
Telephone interface cable  
Second battery charger with spare battery and AC power  
Quick Start Guide

### CS540-XD

Headset and battery  
Base  
Headband  
Headset fit kit

AC power supply  
Telephone interface cable  
Quick Start Guide

### CS520-XD

Headset  
Base  
AC power supply

Telephone interface cable  
Quick Start Guide

### CS510-XD

Headset  
Base  
AC power supply

Telephone interface cable  
Quick Start Guide

71782-01



81423-01



84598-01



84604-01



84605-01



84606-01



86007-01



86540-01



89547-01



89548-01



89549-01



89806-01



## SPARES AND REPLACEMENT PARTS

### PART NO.

71782-01	Ear cushions, leatherette (2) (CS510-XD/CS520-XD)
72742-02	Headband Support (CS510-XD/CS520-XD), <i>image on page 43</i>
81423-01	AC power supply, straight plug
84598-01	CS spare battery (CS540XD/CS545XD)
84604-01	Fit kit, earloops/earbuds/foam ear loop cover (CS540-XD/CS545-XD)
84605-01	Headband (CS540-XD/CS545-XD)
84606-01	Neckband (CS540-XD/CS545-XD)
86007-01	Telephone interface cable
86540-01	Eartips, Earloops (CS540-XD/CS545-XD)
88286-01	Spare battery charging cable and AC adapter, <i>not shown</i>
89525-01	Spare Battery Charging Cable, <i>not shown</i>
89547-01	Headset (CS510-XD)
89548-01	Headset (CS520-XD)
89549-01	Over-the-ear Headset (CS540-XD/CS545-XD)
89804-01	Spare battery charging cable and battery, <i>not shown</i>
89806-01	Spare battery charging cable, AC adapter and battery (CS545-XD)
202599-03	CS510/520 Battery, <i>not shown</i>



71781-01



80287-01



87527-01



88940-01



88941-01



83776-11



84599-01



84609-01



86005-01



37818-11



37820-11



38350-13



38439-11



38633-11



38734-11



60961-35



78887-01



87317-01



87327-01  
201081-01



89280-11



202578-01



211076-01



212539-01

**ACCESSORIES**

**PART NO.**

- 65116-02 On-Line indicator light, *image on page 41*
- 71781-01 Foam ear cushions (CS510-XD/CS520-XD)
- 80287-01 On-line indicator, straight plug
- 87527-01 Foam ear loop covers, 20 Units (CS540-XD/CS545-XD)
- 88940-01 Spare eartips, 25 units, small (CS540-XD/CS545-XD)
- 88941-01 Spare eartips, 25 units, medium (CS540-XD/CS545-XD)

**HEADSET CHARGING ACCESSORIES FOR MULTI-SHIFT ENVIRONMENTS**

- 83776-11 Over-the-head Charging cradle (CS510-XD/CS520-XD)
- 84598-01 Battery (CS540-XD), *not shown*
- 84599-01 Standard Charging cradle - charging only (CS540-XD)
- 84600-01 Deluxe Charging cradle (CS540XD/545XD), *not shown*
- 84609-01 Charge base, 5 units (recommend for CS540XD/CS545XD)
- 86005-01 Charge base, 1 unit, 3 pins with AC power supply (recommend for CS540XD/CS545XD)

**CABLES AND CONNECTORS FOR REMOTE DESK PHONE CALL CONTROL**

- 37818-11 APS-11, Electronic Hook Switch, Siemens®/Funwerk®/Auerswald®/Agfeo®/Aastra®/DeTeWe®
- 37820-11 APT-31, Electronic Hook Switch, Avaya® GmbH (Tenovis)
- 38350-13 APC-43, Electronic Hook Switch, Cisco
- 38439-11 APP-51, Electronic Hook Switch, Poly
- 38633-11 APV-66, Electronic Hook Switch, Avaya (EU24)
- 38734-11 APV-63, Electronic Hook Switch, Avaya
- 60961-35 HL10 handset lifter, Straight Plug
- 78887-01 RD-1 Electronic Hook Switch, Shoretel®/Toshiba®/Adtran®/Allworx® (not available in Europe)
- 85638-01 EHS Extension Cable, Cisco, *not shown*
- 87317-01 APC-45, Electronic Hook Switch, Cisco
- 87327-01 APD-80, Electronic Hook Switch
- 89280-11 APN-91, Electronic Hook Switch, NEC®
- 201081-01 APC-82, Electronic Hook Switch, Cisco
- 202578-01 APU-72, Electronic Hook Switch, Avaya (Nortel®)/Cisco
- 211076-01 APU-76 EHS Cable
- 212539-01 APA-24 Alcatel EHS Cable